

Disconnect the TV Set Top Box


1. Locate the black MVTV Wireless TV Set Top Box



2. On the back you will find the power cord, HDMI cable and the coax cable (Antenna In)




3. Unplug the power cord from the power outlet, unplug the coax cable and HDMI cables from the STB (Set Top Box)
4. Discard the old STB and STB remote. **Please destroy the smart card.**
5. Plug the Coax cable directly into the back of your television by turning the cable until it is tight




Channel Tune/ Scan for New Unscrambled TV System


1. Turn on the TV by using your TV's remote control
2. Press the **input** button on that remote control and select **Live TV**



3. On your TV remote control go to **Menu/ Settings** and select **channels**



4. Select **Channel Scan/ Channel Tuning**



5. Select **Auto Tune/ Auto Scan**
6. Once the scan has completed, exit and your unscrambled channels are ready for viewing!

If channels do not come in after completing these steps, please call the MVTV office at 320.564.4807 for tech support.